



# JÄLC




**Wooden legs - Step 1.1**  
Insert the barrel nuts into the legs.

**Wooden legs- Step 1.2**  
With the frame laying flat on the ground assemble the legs to the frame. Use long M6 screws. Insert self adhesive rubber pads on the two front screws.




**Step 3**  
Attach the threaded rods to the the lower VESA holes on the TV. Use M6 adapter if needed. Screw the distance adjustment nut on the threaded rods.



**Step 4**  
Place the TV on the stand with the threaded rods going through the vertical grooves. Align the front of the TV with the front of the stand. Adjust the distance adjustment nuts accordingly.

**Step 5**  
Attach the fixing nut on the threaded rod and You are done!



## Attention! General warnings!

Read this manual carefully before assembling and using the product. This product is exclusively intended for use in private domains in accordance with this manual and may not be used for commercial purposes. Any other form of use constitutes improper use and can result in material damage and even personal injury. The manufacturer does not accept any liability for damage caused due improper use. Do not use the product if it appears to be damaged in any way. Do not leave children unattended near the product. The product is intended for indoor use only. Do not use in humid rooms or near water. Avoid using locations where shock and vibrations could occur. The product may only be burdened up to the specified maximum weight (25kg). The package contains small parts. Keep away from the reach of small children. The product should be placed in an area where there is no possibility for the product to be tipped over.